



机架及罩壳



机架及罩壳

序号	图 号	名 称	NAME OF PARTS	数量
1	532.02-01-00	机架		1
2	532.13-03	左侧下围板		1
3	532.13-03	左侧下围板		1
4	532.13-16	中后门		1
5	532.13-12	右侧门 (插销弹簧)		1
6	532.13-14	右后门 (插销弹簧)		1
7	532.13-04	左侧门 (插销弹簧)		1
8	532.13-17	左后门 (插销弹簧)		1
9	532.13-06	前下左围板		1
10	532.13-11	前下右围板		1
11	532.13-05	前上左围板		1
12	532.13-10	前上右围板		1
13	532.13-08	前上中围板		1
14	532.13-25-01-00	前门组件		2
15	532.13-09	梭门		1
16	532.13-18	上罩右架		1
17	532.13-19	上罩左架		1
18	532.02-02	机架上框组件		1
19	532.02-01-32	右上支框		1
20	532.02-01-31	左上支框		1
21	532.13-28	后支撑柱		1
22	532.13-26	撑杆		1
23	532.13-27	撑杆堵头		1
24	532.13-21	后盖		1
25	30043696	电柜箱锁 MS509-2左		1
26	532.13-20	上中盖		1
27	532.13-29	上盖撑杆		1
28	532.13-22	前盖		1
29	532.10-01	电控箱部件		1
30	532.02-02-18	关节蹄脚M20×155 (底盘80)		6
31	L08-P-956808-C	2.5寸万向带刹车脚轮		6
32	05-053201000-3	平垫圈 5.3×2×10		60
33	07-0521313-6	弹簧垫圈 5.2×1.3×1.3		60
34	01-505001024-3	内六角圆柱头螺钉 M5×10		68
35	01-505001624-3	内六角圆柱头螺钉 M5×16		6
36	03-605000500-4	六角螺母 M5		6
37	05-065101300-3	平垫圈 6.4×1.6×12		14
38	07-0631616-6	弹性垫圈 6.3×1.6×1.6		14
39	532.13-01	90°液压铰链		1
40	515.30-09	星型旋钮		1
41	05-084161600-3	平垫片 8.5×1×14		24
42	07-0812121-1	弹性垫圈 8.1×2.1×2.1		26
43	01-708001425-3	无槽六角头螺钉		24
44	502.27-60	柜门下安装板		2
45	05-082202000-4	平垫片 8.2×2×20		2
46	01-508006024-3	内六角圆柱头螺钉		1
47	03-60800650-6	六角螺母		1
48	01-105000824-1	内六角沉头螺钉		2

机架及罩壳



机架及罩壳

序号	图 号	名 称	NAME OF PARTS	数量
1	532.02-01-00	机架		1
2	532.13-03	左侧下围板		1
3	532.13-03	左侧下围板		1
4	532.13-16	中后门		1
5	532.13-12	右侧门 (插销弹簧)		1
6	532.13-14	右后门 (插销弹簧)		1
7	532.13-04	左侧门 (插销弹簧)		1
8	532.13-17	左后门 (插销弹簧)		1
9	532.13-06	前下左围板		1
10	532.13-11	前下右围板		1
11	532.13-05	前上左围板		1
12	532.13-10	前上右围板		1
13	532.13-08	前上中围板		1
14	532.13-25-01-00	前门组件		2
15	532.13-09	梭门		1
16	532.13-18	上罩右架		1
17	532.13-19	上罩左架		1
18	532.02-02	机架上框组件		1
19	532.02-01-32	右上支框		1
20	532.02-01-31	左上支框		1
21	532.13-28	后支撑柱		1
22	532.13-26	撑杆		1
23	532.13-27	撑杆堵头		1
24	532.13-21	后盖		1
25	30043696	电柜箱锁 MS509-2左		1
26	532.13-20	上中盖		1
27	532.13-29	上盖撑杆		1
28	532.13-22	前盖		1
29	532.10-01	电控箱部件		1
30	532.02-02-18	关节蹄脚M20×155 (底盘80)		6
31	L08-P-956808-C	2.5寸万向带刹车脚轮		6
32	05-053201000-3	平垫圈 5.3×2×10		60
33	07-0521313-6	弹簧垫圈 5.2×1.3×1.3		60
34	01-505001024-3	内六角圆柱头螺钉 M5×10		68
35	01-505001624-3	内六角圆柱头螺钉 M5×16		6
36	03-605000500-4	六角螺母 M5		6
37	05-065101300-3	平垫圈 6.4×1.6×12		14
38	07-0631616-6	弹性垫圈 6.3×1.6×1.6		14
39	532.13-01	90°液压铰链		1
40	515.30-09	星型旋钮		1
41	05-084161600-3	平垫片 8.5×1×14		24
42	07-0812121-1	弹性垫圈 8.1×2.1×2.1		26
43	01-708001425-3	无槽六角头螺钉		24
44	502.27-60	柜门下安装板		2
45	05-082202000-4	平垫片 8.2×2×20		2
46	01-508006024-3	内六角圆柱头螺钉		1
47	03-60800650-6	六角螺母		1
48	01-105000824-1	内六角沉头螺钉		2